


Model No. AF301Z PNEUMATIC BRAD NAILER



Model No. AF301Z PNEUMATIC BRAD NAILER

Page 1 / 2

Item	Parts No.	Description	I/C	Qty	N/O	Sales	Purch.	Note
001	A0304-0301	EXHAUST VALVE COLLAR		1				
002	A0200-0191	O RING 35.5X1.8		2				
003	A0000-0101	SCREW 5X22		6				
004	A0005-0031	WASHER #5X1.1T		5				
005	A0301-0141	CYLINDER CAP		1				
006	A0311-0121	SEAL,AIR		1				
007	A0100-0221	SPRING		1				
008	A0200-0231	O RING 9.8X2.4		1				
009	A0200-0071	O RING 31X2.5		2				
010	A0308-0241	FIRING VALVE PISTON		1				
011	A0205-0111	GASKET		1				
012	A0305-0071	COLLAR		1				
013	A0303-0011	CYLINDER		1				
014	A0309-0011	BUMPER		1				
015	A0200-0911	O RING 39.4X3.1		1				
016	A0800-0381	SPACER		1				
017	A0401-1161	BODY		1				
018	A0310-0241	NOZZLE		1				
019	A0505-0041	SEAL,AIR		1				
020	A0503-0211	TRIGGER VALVE HEAD "POM"		1				
021	B0700-1401	MAGAZINE ASS'Y		1				
022	A0200-0321	O-RING 3.8X1.5		1				
023	A0504-0001	TRIGGER VALVE STEM		1				
024	A0503-0041	TRIGGER VALVE GUIDE		1				
025	A0200-0331	O-RING 9.8X1.9		1				
026	A0100-0021	COMPRESSION SPRING		1				
027	A0005-0041	E RING 2.5		2				
028	A0500-0191	TRIGGER		1				
029	A0006-0271	STEP PIN 2.9X29		1				
030	A0200-0131	O RING 35X3.5		1				
031	A0306-0231	TAIL COVER		1				
032	A0307-0001	AIR PLUG		1				
033	A0200-0031	O RING 21.3X3		1				
034	A0602-0021	PISTON HEAD		1				
035	A0601-0021	DRIVER BLADE PIN		1				
036	A0011-0051	OUTER SPRNG PN 4X10		1				
037	A0011-0061	INNER SPRING PIN 2.5X10		1				
038	A0600-1721	DRIVER BLADE		1				
039	A0800-0081	SPACER		1				
040	A0801-1041	DRIVER GUIDE		1				
041	A0000-0021	SCREW 4X16		2				
042	A0011-0221	SPRING PIN 2X12		2				
043	A0801-1291	DRIVER GUIDE		1				
044	A0000-0011	SCREW 4X8		5				
045	A0005-0051	WASHER #4X0.9T		4				
046	A0004-0001	HEX. NUT M5		1				
047	A0709-0011	CLICK LEVER		1				
048	A0101-0051	TORSION SPRING		1				

Page 2 / 2

Print Date 05/10/2016