


Model No. TM30D CORDLESS MULTI TOOL



Model No. TM30D CORDLESS MULTI TOOL

Page 1 / 3

Item	Parts No.	Description	I/C	Qty	N/O	Sales	Purch.	Note
001	266429-2	TAPPING SCREW 3X16		12				
002	183E32-3	MOTOR HOUSING SET		1				
C10	263039-6	RUBBER PIN 4		3				
C20	424859-5	CUSHION		2				
D10		INC. 28						
003	852E52-5	TM30D NAME PLATE		1				
004	962151-6	RETAINING RING R-32		1				
005	253368-5	WASHER 16		1				
006	210147-4	BALL BEARING 6902		1				
007	326719-6	CRANK SHAFT		1				
008	456788-4	SPACER 21		1				
009	210147-4	BALL BEARING 6902		1				
010	210144-0	SPHERE BEARING 505		1				
011	961008-8	RETAINING RING S-5		1				
015	144085-7	CRANK HOUSING COMPLETE		1				
016	213987-9	O-RING 25		1				
017	213021-5	O RING 5		1				
018	224455-7	OUTER FLANGE 22		1				
019	266783-4	HEX.SOCKET C.S.H.SCREW M6X20		1				
020	456791-5	SWITCH KNOB		1				
021	424833-3	SPACER		1				
022A	629220-3	DC MOTOR		1				
022C	629220-3	DC MOTOR		1				
022D	629220-3	DC MOTOR		1				
022E	629220-3	DC MOTOR		1				
022F	629220-3	DC MOTOR		1				
022W	629221-1	DC MOTOR		1				
022X	629221-1	DC MOTOR		1				
022Y	629221-1	DC MOTOR		1				
022Z	629221-1	DC MOTOR		1				
023	424467-2	CAP		1				
024	651610-2	SWITCH		1				
025	424860-0	SWITCH COVER		1				
026	620522-0	CONTROLLER		1				
C10	620543-2	LED CIRCUIT		1				
027	644813-5	TERMINAL		1				
028	183E32-3	MOTOR HOUSING SET		1				
C10	263039-6	RUBBER PIN 4		3				
C20	424859-5	CUSHION		2				
D10		INC. 2						
A01	783233-9	HEX. WRENCH 5		1				
A02A	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
C20	838502-4	INNER TRAY		1				
A02D	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
A02E	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				

Please order the parts with a part number.

Print Date 11/10/2016

Model No. TM30D CORDLESS MULTI TOOL

Page 2 / 3

Item	Parts No.	Description	I/C	Qty	N/O	Sales	Purch.	Note
A02F	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
A02W	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
A02X	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
C20	838502-4	INNER TRAY		1				
A02Y	143644-4	PLASTIC CASE COMPLETE		1				
C10	162302-3	LATCH		2				
A03A	456128-6	BATTERY COVER		1				
A03D	196272-4	ADAPTER A SET		1				
A03E	196272-4	ADAPTER A SET		1				
A03F	196272-4	ADAPTER A SET		1				
A03W	196272-4	ADAPTER A SET		1				
A03X	456128-6	BATTERY COVER		1				
A03Y	196272-4	ADAPTER A SET		1				
A04A	***DC10WD	DC10WD BATTERY CHARGER		1				
D10		COMPO-PARTS						
A04D	B-21325	SEGMENT SAW BLADE 85 TMA006		1				
A04E	B-21325	SEGMENT SAW BLADE 85 TMA006		1				
A04F	B-21325	SEGMENT SAW BLADE 85 TMA006		1				
A04W	B-21325	SEGMENT SAW BLADE 85 TMA006		1				
A04X	***DC10WD	DC10WD BATTERY CHARGER		1				
D10		COMPO-PARTS						
A04Y	B-21325	SEGMENT SAW BLADE 85 TMA006		1				
A05A	197393-5	BATTERY BL1016 SET		2				
A05D	B-21353	PLUNGE CUT SAW BLADE 28 TMA009		1				
A05E	B-21353	PLUNGE CUT SAW BLADE 28 TMA009		1				
A05F	B-21353	PLUNGE CUT SAW BLADE 28 TMA009		1				
A05W	B-21353	PLUNGE CUT SAW BLADE 28 TMA009		1				
A05X	197393-5	BATTERY BL1016 SET		2				
A05Y	B-21353	PLUNGE CUT SAW BLADE 28 TMA009		1				
A06D	B-21537	SANDING PAD		1				
A06E	B-21537	SANDING PAD		1				
A06F	B-21537	SANDING PAD		1				
A06W	B-21537	SANDING PAD		1				
A06Y	B-21537	SANDING PAD		1				
A07D	821538-0	TOOL BOX		1				
A07E	821538-0	TOOL BOX		1				
A07F	821538-0	TOOL BOX		1				
A07W	821538-0	TOOL BOX		1				
A07Y	821538-0	TOOL BOX		1				
A08W	197766-2	DUST ATTACHMENT SET		1				
A08Y	197766-2	DUST ATTACHMENT SET		1				
A09E	456128-6	BATTERY COVER		1				
A09F	456128-6	BATTERY COVER		1				
A09W	456128-6	BATTERY COVER		1				
A10E	***DC10WD	DC10WD BATTERY CHARGER		1				

Please order the parts with a part number.

Print Date 11/10/2016

Page 3 / 3

Print Date 11/10/2016